

Must Do --- Important Installation Steps BEFORE the iPod / AUX Interface is Connected

- Ignition key **MUST** be **OFF** and **OUT** with the driver's door open.
- Plug harness into radio and into the vehicle harness.
- Set dip switches to all OFF unless noted in the instructions. Plug in the blue interface box.
- WAIT for 1 full minute before turning on ignition key.
- WAIT for 1 full minute to allow the interface to initialize.
- Follow instructions and "quick reference" cards included in the package for operation instructions.

Pacific Accessory Corporation www.pac-audio.com

Must Do --- Important Installation Steps BEFORE the iPod / AUX Interface is Connected

- Ignition key **MUST** be **OFF** and **OUT** with the driver's door open.
- Plug harness into radio and into the vehicle harness.
- Set dip switches to all OFF unless noted in the instructions. Plug in the blue interface box.
- WAIT for 1 full minute before turning on ignition key.
- WAIT for 1 full minute to allow the interface to initialize.
- Follow instructions and "quick reference" cards included in the package for operation instructions.

Pacific Accessory Corporation www.pac-audio.com