

# NISSAN Quest



## iPod

**\*\*READ THIS FIRST\*\***

### Changing Sources (iPod, HD Radio, \*Satellite Radio, AUX)

- Press the "FM/AM/SAT" button until "Sat" is displayed
- Press the "Seek ▲" button until the source you want is displayed
- Press the "Tune ▼" button to select the source

\*if available

#### Seek ▲

- Press to advance to the next track
- Press to advance to the next option in the browse menu


#### Seek ▼

- Press to go back to the previous track
- Press to go back to the previous option in the browse menu

Display Button – Press to toggle through display modes.

#### Scan

- Press to exit browse menu
- Press while listening to iPod to toggle through random modes.



Tune ▲ – Press to go back one step while in the browse menu

Tune ▼  
• Press to enter into the browse menu  
• Press to make a selection while in the browse menu

AM/FM/SAT Button – Press to enter into Sat mode or to switch modes within the Media Gateway

## Browsing Example:

To select the song "Star-Spangled Banner" through the Artist category

1) Press the Tune ▼ button to enter into the Browse menu. The radio will display "PL:List"

2) Press the Seek ▲ button until radio displays "AR:Artist". Press the Tune ▼ button to select. Radio will display "AR:All"

3) Press the Seek ▲ button until radio displays "AR:Francis Scott Key". Press the Tune ▼ button to select. Radio will display "AL:All".

4) Press the Seek ▲ button until radio displays "AL:Patriot Hits Vol.1". Press the Tune ▼ button to select. Radio will display "TR:All".

7) Press the Seek ▲ button until radio displays "TR:Star-Spangled Banner". Press the Tune ▼ button to select. Song will begin to play and the display will show track info.

(Actual Radio Appearance may differ from representation.)

**\*\*READ THIS FIRST\*\***

## Changing Sources (iPod, HD Radio, \*Satellite Radio, AUX)

- Press the "FM/AM/SAT" button until "Sat" is displayed
- Press the "Seek ▲" button until the source you want is displayed
- Press the "Tune ▼" button to select the source

\*if available

### Seek ▲


- Press to seek up to the next available station
- Press to move forward through the preset menu

### Seek ▼

- Press to seek down to the next available station
- Press to move backwards through the preset menu

Display – press to toggle through display modes

Scan – Press to enter/exit the browse menu



### Tune ▲

- Press to manually tune up
- Press to store presets while in the preset menu

### Tune ▼

- Press to manually tune down
- Press to recall presets while in the preset menu

AM/FM/SAT Button – Press to enter into Sat mode or to switch modes within the Media Gateway

## HD RADIO EXAMPLE

To select an HD radio station.

Press the 'SEEK ▲' button to get to the desired station. The Radio will auto lock on to an HD Radio Station if available example: 92.5 HD1 MHZ  
When locked into an HD Radio Station, press the 'SEEK ▲' button up to access multi-cast HD Station(s). (if available) example: 92.5 HD2 MHZ

To store a radio station into preset memory.

Press the "Scan" button to enter the Preset Menu. Press the "Seek ▲" button until the location you want is shown Press the "Tune ▲" button to store the preset Radio will display "PR Saved"

To recall a station stored into preset memory.

Press the "Scan" button to enter the Preset Menu. Press the "Seek ▲" button until the preset you want to recall is displayed. Press the "Tune ▼" button to select the preset.

(Actual Radio Appearance may differ from representation.)