




Toyota/Lexus/Scion




Browsing Example:
To select the song "Star-Spangled Banner" through the Artist category



Toyota/Lexus/Scion



To select an HD radio station and store presets.



Recalling Presets

- 1) Press the preset button (1-6) that corresponds to the preset you wish to recall.

Changing Modes:

- 1) Leaving and re-entering the SAT mode (simply push the AM/SAT button to switch to AM, then again to switch back to SAT) will enter the mode select menu. The word "BUSY" may be displayed for a few seconds. When in the mode select menu one of the following will be displayed; "SAT"/"HD RADIO"/"IPOD"/"AUX1", or "AUX2". Turn the rotary knob until the desired source is displayed on the screen. Press "Preset #3" to select the displayed mode.